


# Decora Digital™ Dimmer & Timer App Quick Guide

## Basic Control




Summary of all paired devices

Choose which paired device you want to control

Summary of all unpaired devices

Tap to change bulb type, fade rates\*, min and max light levels\*, preset light levels\* and LED locator light and brightness settings



Tap to edit device name

Tap to turn lights on and off

Slide to adjust light level to dim or brighten

Tap to set countdown timer

Tap to schedule one or multiple timed events to turn lights on or off automatically during programmed days and times


Tap to randomize scheduled events

\* Only applicable to dimmer functions.


## Sleep Timer

Tap to enter time manually

Tap to choose preset time



## Scheduled Events




Tap to schedule lights to turn on or off for programmed event

Slide to select the brightness level for event\*

Tap to select day(s) of the week for the event

Tap to select the event time: sunrise, sunset or set a specific time



\* Only applicable to dimmer functions.


## Device Settings

Tap to turn the LEDs on device that display status and brightness level off or on

Tap to change fade rate that controls time for lights to fade on and off

Tap to turn on lights to preset level

Tap to reset authentication code



Tap to change the bulb type

Slide to set min & max light levels

Advanced settings for diagnostics and to set date, time and location

Visit our Website at: [www.leviton.com/decoradigital](http://www.leviton.com/decoradigital)

© 2018 Leviton Manufacturing Co., Inc. All rights reserved.  
All trademarks are the property of their respective owners.



**Leviton Manufacturing Co., Inc. World Headquarters**

201 North Service Road, Melville, NY 11747-3138  
Telephone: 1-800-323-8920 FAX: 1-800-832-9538  
Tech Line (8:30AM-7:00PM E.T. Monday-Friday): 1-800-824-3005  
G-9626A