

## How to Pair

















- **Step 1**—Determine which **LOAD CONTROL DEVICE** will be used to create and manage the GreenConnect network **Note -** the battery-powered Companion Dimmer, Switch, Sensor, or Receptacle cannot create a GreenConnect network
- **Step 2**—Press and hold the test button or top paddle for approximately seven seconds, until the LED blinks amber once, then release
  - The LED will first blink to indicate the device status after approximately four seconds
  - The LED will blink amber rapidly to indicate the device is in the main menu
  - Tap twice to create a GreenConnect network
  - The device will toggle the load ON/OFF twice, and the LED will blink green slowly to indicate the network is open
  - The LED will pause and blink red once every 60 seconds for each device enrolled in the network
- **Step 3**—To add devices to the network, press and hold the test button or top paddle until the LED blinks amber once, then release (approximately seven seconds)
  - The LED will first blink to indicate the device status after approximately four seconds
  - The LED will blink amber rapidly to indicate the device is in the main menu
  - Tap once to search for a network to join
  - The LED will start blinking green slowly
  - Upon successful enrollment, all devices in the network will toggle ON/OFF twice
- **Step 4**—Repeat until all devices have joined the network: press and hold the test button or top paddle until the LED blinks amber once, then release after approximately seven seconds.
  - The LED will first blink to indicate the device status after approximately four seconds
  - The LED will blink amber rapidly to indicate the device is in the main menu
  - Tap once to search for a network to join
  - The LED will start blinking green slowly
  - Upon successful enrollment, all devices in the network will toggle ON/OFF twice
- Step 5—To close the network, tap the test button or top paddle of the device managing the network once
  - All devices in the network will toggle ON/OFF twice
- Step 6—Adjust settings for Wireless PIR Sensor with Integrated Photocell as needed
  - Sensor settings are saved in the load controller managing the network
  - Default Settings:
    - Mode: Auto-ON/Auto-OFF
    - Sensitivity: High
    - Occupancy Time-Out: 15 min
    - Partial-OFF: Disabled
    - Auto-ON level: 50%
    - Photocell: Disabled



## Changing System Settings

- Go to the main menu on the network manager
- Tap the number of times that corresponds to the menu you want to access
- The LED will pause its amber blinking, then blink green the number on the menu, pause again, and blink amber the current menu setting saved (default)
- Tap the number of times that corresponds to the new setting
- Observe the LED blink back to confirm setting was changed
- Press and hold until the LED blinks amber once to return to the previous menu or to exit programming

## **Feature Menus**

Feature # 3: Occupancy Auto-ON Level		
Setting #	Value	
1	100%	
2	50%	
3	25%	
4	Manual-ON (vacancy)	
5	Restore last level (default)	

Feature # 4: Occupancy Sensitivity		
Setting #	Value	
1	Medium	
2	Low	
3	High (default)	

Feature # 5: Primary Time-Out		
Setting #	Value	
1	Test mode (30 seconds for five minutes then reverts to prior setting)	
2	60 minutes	
3	30 minutes	
4	15 minutes	
5	5 minutes	
6	Disabled	

Feature # 6: Partial-OFF Level		
Setting #	Value	
1	Disabled (Default)	
2	50%	
3	25%	

Feature # 7: Secondary Time-Out		
Setting #	Value	
1	5 minutes	
2	15 minutes (Default)	
3	30 minutes	
4	60 minutes	

Feature # 8: Daylighting Target		
Setting #	Value	
1	5 minutes	
2	25 footcandles	
3	35 footcandles	
4	45 footcandles	

Feature # 9: Secondary Level	
Setting #	Value
1	0% (Default)
2	50%
3	25%



## Leviton Manufacturing Co., Inc. Lighting & Controls

10385 SW Avery Street, Tualatin, OR 97062 **tel** 800-736-6682 **tech line** (6:00AM-4:00PM PT Mon-Fri) 800-959-6004